




## **CLASSIC DROP SPINDLE**







Spin the spindle clockwise and allow the leader to join onto your prepared fibres.




While keeping the leader pinched with one hand, draft the fibres down.



Slowly slide your fingers back up the drafted fibres allowing the twist to follow. Once twisted, the yarn will support the weight of the spindle.

DS09022012V2



Keep the spindle spinning while drafting more yarn until the spindle reaches the floor.



Wind the yarn around the shaft to form a cone & then repeat the process. Slide the cone off the shaft and use either as a single or ply 2 together with the spindle spinning anti-clockwise.

Ashford Handicrafts Limited 415 West Street, Ashburton 7700, New Zealand Telephone 64 3 308 9087 sales@ashford.co.nz www.ashford.co.nz